

# Instructivo configuración

## Wifi módem EMTA ARRIS modelo: TG862G



1. Conéctese al internet del módem, de manera alámbrica con un cable de red o vía Wifi con un equipo inalámbrico (celular, Tablet, laptop).

Accede a la configuración del módem escribiendo en tu navegador una de las siguientes direcciones **IP: 192.168.100.1/** ó **192.168.1.100/**.



2. Le aparecerá la siguiente pantalla, ver figura 2. En el menú que aparece a la izquierda seleccione **Wireless Setup**.

En la siguiente pantalla coloque **Usuario: admin** y **Contraseña: password**.



3. En la opción Wireless Network Name (SSID) coloque el nombre del Wifi deseado, luego vaya a la opción **Pre-Shared Key** y coloque la contraseña, debe ser de mínimo 8 caracteres y no debe llevar ningún símbolo.

Guarde los cambios seleccionando la opción **“Apply”**.

**BASIC SETUP**

**System Basic Setup**

While your system has many configuration options, the options on this Basic Setup page are those required by most users. Click the tabs to access the other configuration pages to set advanced options. Hover the mouse pointer over the question mark icon next to an option to view a description of that option. For changes to take effect, you must click the Apply button.

**Basic Setup**

Host Name: prueba ?

Enable Wireless:  ?

Wireless Network Name (SSID): **Altice RD** ?

Broadcast Network Name (SSID):  ?

User Name: technician ?

Tx Power Level: High ?

Channel: Auto ?

Language: English ?

Security Mode: WPA2-PSK ?

**Security Settings (WPA/WPA2 PSK)**

Encryption Algorithm: TKIP/AES ?

Pre-Shared Key: **123456789** ?

**WPS Settings**

WPS Enable:  ?

Device PIN Code: 48705097 ?

Encryption Mode: PBC ?

Enrollee PIN Code:  ?

Start WPS Association:  ?

**Apply**

